

TECH NOTE - Correct Procedure To Tighten F- Connectors

F connector tightening procedure. Placing a 7/16" wrench on the chassis connector while holding it tight, place another 7/16" wrench over the Male connector housing and tighten until snug. Do not over tighten this F connector. View pictures below.

